

BAR KIT

Item # CPBK31



Tools Required:

- ½" wrench
- ½" socket
- Drill
- ⅝" x 6" Drill Bit
- Tape Measure (optional)
- Small Hammer

Components:

- (12) Bars
- (1) Bolt Kit



SCAN TO WATCH
ASSEMBLY VIDEO

Instructions:

Step 1: Install two bars in each of the 6 open sections on the inside of the rings.

Step 2: Hold upright in place vertically between top and second ring with the bow to the inside of the feeder.

Step 3: Drill ⅝" hole through bar and ring and use provided hardware to fasten each bar. 2 bolts per bar.

Step 4: Repeat steps 2 and 3 until all bars are mounted.

Step 5: Tighten lock nuts.

NOTE: We suggest not using a cordless drill or impact; nuts should be tightened by hand.