

SKIRT KIT

Item # CPSKT



Tools Required:

- ½" Wrench
- ½" Socket
- Small Hammer
- Drill
- 5/16" x 6" Drill Bit

Components:

- (6) Sheets of Skirting Material
- (1) Bolt Kit



SCAN TO WATCH
ASSEMBLY VIDEO

Instructions:

NOTE: Each sheet will completely enclose the bottom three rings between each leg.

Step 1: Hold skirt material in place and drill three 5/16" holes through the skirt and each of the three bottom rings (total of nine bolts per sheet).

Step 2: Insert bolts through the drilled holes.

Step 3: Place washers on the bolts and tighten lock nuts.

NOTE: We suggest not using a cordless drill or impact; nuts should be tightened by hand.